

DISENGAGING BOL6 OPENER FOR MANUAL OPERATION



- To disengage BOL6 unit pull the **red string**^① that is attached to a **black plastic handle**^②. Once disengaged the **black plastic handle**^② will point towards the floor. The door can then be used manually. To re-engage push the **black plastic handle**^② up.