


# DISENGAGING FORZA OPENER FOR MANUAL OPERATION



- To disengage Forza BFOR12 unit pull the **red string**<sup>①</sup> and move door manually to disengage the **trolley**<sup>②</sup>. The disengagement device is sprung loaded, so to re-engage the unit ensure the **trolley**<sup>②</sup> is re-engaged with the **belt joiner**<sup>③</sup>. Alternatively, run the unit until it automatically re-engages.