

HOW TO PROGRAMME A BRD1A ROLLER DOOR OPENER



- Setting the Limits – with the unit installed on the right hand side of the door (standing inside the garage looking outwards). Put the unit into manual mode with the **red release handle**^① and push the door by hand to the desired open position. Remove the black cover to expose the **limit cams**^②. Loosen the **2 wing nuts**^③ slightly that lock the cams into place, so that the cams can be rotated by hand. Rotate the **limit cams**^② clockwise by hand in the direction of the **limit micro switch**^④ until the cam clicks the open **limit micro switch**^④. Now move the door by hand to the desired closed position. Rotate the closed **limit cams**^② by hand anti-clockwise until the cam clicks the closed **limit micro switch**^④. Then re-tighten the **2 wing nuts**^③. Re-engage the unit with the **red release handle**^① and the opener is ready to use.

* The limit cams will be reversed for a left hand mounted unit.

- To program a remote to this unit, press the **code button**^⑤ and hold until the **red LED**^⑥ illuminates. Press the **desired button**^⑦ that you wish to code on your remote for 2 seconds. The **LED**^⑥ on the control console will switch off. Release the button on the remote for 2 seconds and the **LED**^⑥ on the control console will begin to flash. When this **LED**^⑥ stops flashing the remote programming is complete.

