


# HOW TO PROGRAMME A FORZA (BFOR12) OPENER



⑤ ① ②

③

④



⑥

- Limit Setting – starting with the door in the closed position, press the **“P” button**<sup>①</sup> for 5 seconds. The unit will beep once and **“1”** will be displayed on the **screen**<sup>②</sup>. Press the **“P” button**<sup>①</sup> again and **“1”** will flash on the **screen**<sup>②</sup>. Press and hold the **“+” button**<sup>③</sup> and the door will move in the up direction. Release the **“+” button**<sup>③</sup> once the door has reached the desired open position. The open position may be fine tuned by pressing the **“-” button**<sup>④</sup>. Once happy with your open position press the **“P” button**<sup>①</sup> once to save your setting
- To set the close limit, press the **“+” button**<sup>③</sup> once again and **“2”** will be displayed on the **screen**<sup>②</sup>. Press the **“P” button**<sup>①</sup> again and **“2”** will flash on the **screen**<sup>②</sup>. Press and hold the **“-” button**<sup>④</sup> and the door will move in the down direction. Release the **“-” button**<sup>④</sup> once the door has reached the desired closed position. The closed position may be fine tuned by pressing the **“+” button**<sup>③</sup>. Once happy with your closed position, wait 2 seconds and press the **“P” button**<sup>①</sup> to save the settings.
- The force now needs to be set. Press the **“+” button**<sup>③</sup> once again and **“3”** will be displayed on the **screen**<sup>②</sup>. Press the **“P” button**<sup>①</sup> again and **“3”** flashes on the **screen**<sup>②</sup>. The door will open automatically. Press **“P” button**<sup>①</sup> when the door stops and then press **“P” button**<sup>①</sup> again and the door will close automatically. Once the door stops, press **“P” button**<sup>①</sup> continuously for 5 seconds to save your settings and exit programming.
- To program the remote to this unit, press the **“S” button**<sup>⑤</sup> until **“0”** appears on the **screen**<sup>②</sup> and then release the **“S” button**<sup>⑤</sup>. Press the **desired button**<sup>⑥</sup> on your remote that you wish to use. The **“0”** on the **screen**<sup>②</sup> will disappear and your remote has been coded.