


HOW TO PROGRAMME A REMOTE TO A BRD1A OPENER



- Remove the black cover of the control console to expose the **code button**^①.
- To program a handset to a BRD1A roller door opener, press the **code button**^① and hold until the **red LED**^② illuminates. Press the **desired button**^③ that you wish to code on your remote for 2 seconds. The **LED**^② on the control console will switch off. Release the button on the remote for 2 seconds and the **LED**^② on the control console will begin to flash. When this **LED**^② stops flashing the remote programming is complete.

