


MANUALLY OPERATING ST50EVOB/ST50EVOC OPENERS



- DO NOT USE THE **RED HANDLE**^① TO OPEN AND CLOSE THE GARAGE DOOR

To Disengage the Garage Door

- Pull and hold the **red manual release rope**^①.
- Move the garage door slightly—this will disengage the garage door from the **trolley**^②.
- Release the **red manual release rope**^①.
- The garage door can now be opened by hand.

To Re-engage the Garage Door

Either

- Move the garage door back to the original position it was disengaged from, the **trolley**^② will automatically re-engage.
- Operate the unit via remote, when the **trolley**^② passes the garage door position it will automatically re-engage.